Weiss DAC EQ curves

1. Open the DAC's web interface by putting the ip address of the unit into a web browser once it's plugged into your network.
2. On the main page, scroll down to the "DSP Plugins" portion and select "Headphone EQ"



3. Click "Enable", and then set your EQ curve for your specific Audeze headphones:



If you don’t see these options, you may need to update your Weiss DAC firmware. You can do that by clicking the “Check for Update” button below the DSP Plugins.